

FANTASTIC FUSIBLES

THE BASICS

TRY ONE!

IMPORTANT

Create in well ventilated area.

DO NOT set oven on Broil!

DO NOT touch pan or SD after removing from oven.

DO NOT set hot pan on counter or surfaces that are not heat safe!

INFORMATION

A toaster oven is ideal, but a home oven can be used.

PYREX or GLASS baking pan should have a FLAT surface.

A Safety Razor Blade can be used to scrape and clean pans.

1. Create three different sized SD pieces: Big, medium and small. (Fun to use three different colors of SD plastic.)
2. Layer cut-out pieces on top of each other. This will give you a size check as well as an overall view of colors and placements.
3. Bake pieces. Cool.
4. Boost oven temperature to 450°F.
5. Layer pre-baked SD pieces on a GLASS or PYREX baking pan.
6. Carefully put pan into oven to re-bake. Fusing is complete when all SD edges are completely rounded or melted. (Takes 15-30 minutes – depending on your oven and size of SD piece.)
7. Using a thick pot holder, remove pan from oven and place on heat safe surface. Pan should be cool to the touch before piece can easily be removed from pan.

A FEW FUSING FACTS

1. Some colors disappear when fusing. Place FR&R pieces COLORED SIDE DOWN. Colors stay. Plastic turns clear.
2. Holes created with a 1/8" paper punch will disappear. Try larger punch.
3. Use scraps – even holes from paper punch catcher – bake and shrink. Lay pieces on prebaked SD shape. Fuse and remove from oven. Try swirling colors with a needle...push down with folded aluminum foil if necessary.
4. Can add Embossing Powders after removing SD from 450°F oven and plastic is really hot.

Unending Applications!!